



Communicator FIRECOM for fire alarm control panel

Installation manual

January, 2025



Contents

SAFETY PRECAUTIONS	4
1. DESCRIPTION.....	5
1.1 SPECIFICATIONS	6
1.2 ELEMENTS OF THE <i>FIRECOM</i> COMMUNICATOR.....	7
1.3 PURPOSE OF TERMINALS	8
1.4 LED INDICATION OF OPERATION.....	8
1.5 COMPONENTS NECESSARY FOR INSTALLATION	9
2 POWERING THE COMMUNICATOR	9
2.1 MAIN POWER SUPPLY.....	9
2.2 BACKUP POWER SUPPLY.....	9
2.3 COMMUNICATOR KIT	10
3 INSTALLATION OF THE SYSTEM	10
3.1 ORDER OF CONNECTING DEVICES	11
3.2 CONNECTING SENSORS	11
3.3 CONNECTING SMOKE DETECTORS.....	12
3.4 SCHEMATIC FOR CONNECTING THE COMMUNICATOR TO A FIRE ALARM CONTROL PANEL	13
3.5 SCHEMATIC FOR CONNECTING THE FIRE PANEL ESPA4.4.4	14
3.6 SCHEMATIC FOR CONNECTING THE FIRE PANEL NSC SOLUTION.....	15
3.7 SCHEMATIC FOR CONNECTING THE FIRE PANEL INIM SMARTLINE	17
3.8 SCHEMATIC FOR CONNECTING THE FIRE PANEL C-TEC CAST ZFP	19
3.9 SCHEMATIC FOR CONNECTING A TEMPERATURE SENSOR.....	24
3.10 SCHEMATICS FOR CONNECTING A RELAY AND AN LED INDICATOR.....	24
3.11 SCHEMATICS OF CONNECTING THE INPUTS OF THE FIRE PANEL TO THE COMMUNICATOR.....	25
3.12 SCHEMATICS FOR CONNECTING IO SERIES EXPANDER MODULES	25
3.13 TURNING ON THE COMMUNICATOR.....	26
4 QUICK CONFIGURATION USING <i>TRIKDISCONFIG</i> SOFTWARE.....	27
4.1 SETTINGS FOR CONNECTING TO <i>PROTEGUS2</i> APP.....	27
4.2 SETTINGS FOR CONNECTING TO CENTRAL MONITORING STATION	29
5 REMOTE CONTROL	31
5.1 ADDING THE COMMUNICATOR TO <i>PROTEGUS2</i> APP	31
5.2 CONFIGURATION AND CONTROL VIA SMS MESSAGES.....	32
5.3 CONTROL PGM OUTPUTS USING PHONE CALLS.....	33
6 DESCRIPTION OF <i>TRIKDISCONFIG</i> WINDOWS	34
6.1 DESCRIPTION OF <i>TRIKDISCONFIG</i> STATUS BAR.....	34
6.2 “SYSTEM OPTIONS” WINDOW	35
6.3 “REPORTING TO CMS” WINDOW	37
6.4 “USERS & REPORTING” WINDOW	39
6.5 “MODULES” WINDOW.....	41
6.6 “ZONES” WINDOW	42
6.7 “PGM” WINDOW	43
6.8 “SENSORS” WINDOWS.....	45
6.9 “SYSTEM EVENTS” WINDOW	46
6.10 “EVENTS LOG” WINDOW	47
6.11 RESTORE DEFAULT SETTINGS	47
7 SETTING PARAMETERS REMOTELY	47



Communicator *FIRECOM* for fire alarm control panels

8	COMMUNICATOR TESTING.....	48
9	UPDATING FIRMWARE	48



Safety precautions

The communicator should be installed and maintained only by qualified personnel.

Please read this manual carefully prior to installation in order to avoid mistakes that can lead to malfunction or even damage to the equipment.

Always disconnect the power supply before making any electrical connections.

Any modifications, modernization or repairs not authorized by the manufacturer shall render the warranty void.



Please adhere to your local waste sorting regulations and do not dispose of this equipment or its components with household waste.



1. Description

Communicator **FIRECOM** meets the requirements of standard EN 54-21:2006; EN 54-4:1997/AC:1999/A1:2002/A2:2006.

The product complies with the performance requirements of EN54-21 standard Annex A for type 1 transmission system type.

Communicator **FIRECOM** Certificate No: 1922-CPR-2083. Fire detection and fire alarm systems. Alarm transmission and fault warning routing equipment. Power supply equipment.

The product is certified by notified product certification body: No.1922 "Dedal", Nesebar Mladost str. 50, Bulgaria, 8230

Trikdis technical support contacts: support@trikdis.lt, +37067422877.


The **FIRECOM** is used for transmitting fire alarm control panel messages via LAN and/or cellular networks to the Central Monitoring Station's receiver.

Principle of operation. When an input (zone) of the communicator is violated, the **FIRECOM** will transmit an event message to the Central Monitoring Station's receiver or to the **Protegeus2** app using mobile internet and/or LAN network. It can also send SMS messages and make phone calls. The communicator is available with 4G modem.

Features

Messages to the security company

- Sends events via the built-in LAN module or cellular 4G modem.
- Events are sent via available communication channels with the selected priority.
- Any CMS can receive reports, as long as they have TRIKDIS software/IP receiver or any other manufacturer's IP receiver supporting SIA DC-09 IP protocol.
- Prioritizing the transmission of events to the CMS: messages are first transmitted to the CMS and only then to **Protegeus2**.
- Possibility to send event reports to CMS of two different security companies.
- Event messages are sent in Contact ID or SIA codes.



Messages to users

- Calls selected phone numbers (up to 8 users).
- Sends SMS messages about events.
- "Push" and special sound event notifications using the **Protegeus2** application.
- Remote temperature monitoring.

Remote control of outputs

- Via **Protegeus2** app.
- By calling the device's phone number.
- Via SMS messages.

Settings and installation

- Quick and easy installation.
- Device configuration either using an USB cable or remotely using **TrikdisConfig** software.
- Remote updating of firmware.
- Two access levels (types of accounts) for setting parameters: for the installer and for the administrator.

Inputs and outputs

- 3 relay outputs (1 A, 30V DC).
- Input "FLOOP" is intended for connection of two-wire fire detectors.
- 10 I/O terminals, each of which can be set as an input (IN) or output (OUT) terminal. Selectable Input (IN) types: NC, NO, EOL, EOL-T, ATZ, ATZ-T. Resistors of different ratings can be used in EOL and ATZ circuits.



Communicator **FIRECOM** for fire alarm control panels

- With **iO** expander modules, the number of IN inputs can be expanded up to 32 units, and the number of OUT outputs can be expanded up to 16 units.
- RS485 bus is used to connect **iO** series expander modules.
- RS485 2 bus is used to connect fire alarm control panels.

1.1 Specifications


Parameter	Description
LTE modem frequencies: EU (Europe) LA (Latin America)	LTE-FDD: B1/B3/B5/B7/B8/B20/B28 LTE-FDD: B2/B3/B4/B5/B7/B8/B28/B66
Power supply voltage	15-32 V DC, 2.5A
Current consumption	Up to 50 mA (stand-by). Up to 300 mA (transmitting). Up to 2.5 A (after connecting the maximum possible load with external devices).
Backup power source [BAT]	12 V lead – acid battery, 4 Ah/7 Ah
Battery charge current	Up to 500 mA
Power voltage and current for external devices [AUX]	12 V DC, up to 1 A
Transmission protocol	TRK, SIA DC-09_2007, SIA DC-09_2012, SIA DC-09_IPcom, TL150
Encryption key	6 symbol encryption key.
Connection to CMS	TCP/IP or UDP/IP
Event codes	Contact ID, SIA codes.
LAN module	Yes, built-in
LAN network configuration type	DHCP or manual
SIM card	1, NANO size
Report transmission directions	- To main and backup receivers of 2 different security companies; - To Protegun2 cloud, to iOS/Android Protegun2 mobile apps; - To 8 mobile phones via SMS messages. - Calls 8 mobile phones.
Event reporting transmission channels	4G, Ethernet (LAN), SMS, call
Message encryption	Yes
Internal clock	Yes
User	40
Dual purpose terminals [I/O]	10; IN or OUT function selected during programming. When IN is selected, available types: NC, NO, EOL, EOL_T, ATZ, ATZ_T. When OUT is selected, the terminal becomes open collector (OC) type with up to 100 mA current
No. of groups	8
No. of zones	10 (20 zones if using ATZ), (can be expanded to 32 zones using expanders)
No. of PGM outputs	3 relay (1 A, 30V DC). (can be 13 if IO terminals are set as outputs. Can be expanded to 16 outputs with expanders)
Buffer memory capacity	60 events
Events log memory	Up to 1000 events. Oldest entries deleted automatically.



Communicator **FIRECOM** for fire alarm control panels

Parameter	Description
Configuration	Remotely using TrikdisConfig software or locally using USB Type-C.
1-Wire data bus length [1 WIRE]	Up to 30 m
Compatible temperature sensors	Maxim®/Dallas® DS18S20, DS18B20; AM2301 series
Max. number of temperature sensors connected to 1-Wire data bus	8 (Dallas) or 1 (if an AM2301 series sensor is used)
RS485 bus	2
RS485 bus length	Up to 100 m
Supported modules	IO-8 – expander module; IO-MO – iO-WL radio wave transceiver; IO-LORA – expander module; IO8-LORA – expander module; PB-LORA – panic button; REL-LORA – expander module; ESPA 4.4.4 - fire alarm control panel; NSC Solution – fire alarm control panel; INIM Smartline - fire alarm control panel; C-TEC Cast ZFP – fire alarm control panel.
Operating environment	Temperature from -10 °C to +50 °C, relative air humidity – up to 80% at +20°C.
Dimensions	235 x 205 x 92 mm
Weight	1.35 kg

1.2 Elements of the **FIRECOM** communicator





1. Connectivity and operation indicator lights.
2. Button. Not used.
3. Backup power supply terminal block.
4. Main power supply terminal block.
5. RESET button.
6. External terminal block.
7. "1-WIRE" data bus terminal block.
8. RJ45 LAN connector.
9. PGM relay terminals.
10. Nano-SIM card holder (SIM2 – not used).
11. SMA screw-on type connector for GSM antenna.
12. USB Type-C connector for configuring the communicator settings.

1.3 Purpose of terminals

Terminal	Description
Power terminal „+“	Power supply terminal (15 – 32 V DC positive terminal)
Power terminal „-“	Power supply terminal (15 – 32 V DC negative terminal)
BAT+	Backup power supply positive terminal 12 V
BAT-	Backup power supply negative terminal 12 V
AUX+	Positive 12 V power terminal for external devices
AUX-	Common negative terminal
A1 RS485	RS485 bus is for connecting <i>iO</i> expansion devices
B1 RS485	
A2 RS485	RS485 bus for connecting fire alarm control panel
B2 RS485	
IO1 – IO10	Input/output terminals (default setting – input)
C	Common negative terminal
AUX+	Positive 12 V power terminal for external devices
FLOOP	Terminal for connecting a 2-wire fire detector
+5 V	Positive 5 V, 0.2 A power terminal for <i>1-Wire</i> devices
1 WIRE	"1-Wire" data bus terminal
C	Common negative terminal
NO1/C1/NC1	1st PGM relay output terminals
NO2/C2/NC2	2nd PGM relay output terminals
NO3/C3/NC3	3rd PGM relay output terminals

1.4 LED indication of operation

Indicator	Light status	Description
SIM	Off	Not connected to GSM network
	Green blinking	SIM card is registering on GSM network.
	Green solid	SIM card registered on GSM network.
	Green solid and yellow blinking	The communicator is connected to GSM network. Sufficient GSM signal strength level for 4G is 3 (three yellow flashes).
ETH	Green blinking	LAN cable disconnected or DHCP problem.
	Green solid	Connected to LAN network.



Indicator	Light status	Description
DAT / DATA	Off	All event messages sent
	Green solid	Message is being sent
	Yellow solid (DAT)	There are unsent event messages in buffer memory
STA / TROUBLE	Green blinking (STA)	No operational problems
	Off (TROUBLE)	No operational problems
	1 red flash	No SIM card inserted
	2 red flashes	The PIN code of the SIM card is incorrect
	3 red flashes	Unable to connect to GSM network
	4 red flashes	Unable to connect to the IP receiver using the primary channel
	5 red flashes	Unable to connect to the IP receiver using the secondary channel
	6 red flashes	No DC power
	7 red flashes	AUX output fault (overcurrent or overvoltage)
	8 red flashes	Battery failure
	9 red flashes	The LAN cable is disconnected
10 red flashes	LAN DHCP problem	
FPS / POWER	Off	Power supply is not connected
	Green solid	No problems with power supplies
	1 green flash	No AC power
	2 green flashes	Insufficient backup power supply voltage

1.5 Components necessary for installation

Before beginning installation, make sure that you have:

1. A USB Type-C type cable for configuration.
2. At least 4-wire cable for connecting the communicator to the fire alarm control panel.
3. A flat-head 2,5 mm screwdriver.
4. An external GSM antenna if network coverage in the area is poor.
5. An activated nano-SIM card (PIN code requests can be turned off).
6. The manual of the fire alarm control panel that the communicator will be connected to.

Order the necessary components separately from your local distributor.

2 Powering the communicator

2.1 Main power supply

The communicator must be powered by a DC source. A backup power supply – a 12 V battery – must be connected to the system to ensure the supply of power is uninterrupted.

2.2 Backup power supply

If there are problems with powering the system from the main power supply, an “*DC Fault*” event report will be generated and the panel will automatically switch to the backup 12 V battery. If the battery’s voltage falls to 11,5 V, a “*Low Battery*” event report will be generated. The battery will be disconnected if the voltage falls below 9,5 V. If DC voltage is restored, an “*DC Restore*” report will be generated and the battery charging process will begin automatically. When the battery’s voltage rises to 12,6 V, a “*Battery Restore*” event report will be generated.



2.3 Communicator kit

Name	Quantity
FIRECOM communicator board with antenna, built into a metal housing	1 pc.
Metal housing with Mean Well impulse power supply	1 pc.
Resistor 10 kΩ	20 pcs.
Wire for connecting battery	1 pc.
Tamper sensor	1 pc.
Terminal block with 3,15 A fuse	1 pc.
Fastening elements (screws - 4 pcs., nylon plugs - 4 pcs.).	1


Note: USB cable (Type-C type) for programming the communicator sold separately.

3 Installation of the system

The communicator board is installed into a mounting housing that already has a DC power supply with a 3,15 A fuse installed and also has space intended for a backup battery.


Dimensions of the FIRECOM board

The picture below shows the dimensions of the board and its mounting holes (in millimeters), and also the locations of the holes.





3.1 Order of connecting devices




1. If you are using a SIM card, insert the activated SIM card into the SIM card holder.
2. If you are using LAN, connect the LAN cable.
3. Using the given connection schematics and the connection schematics for every device to be connected, connect fire sensors, signalers and controlled devices.
4. Connect the AC power supply wires to the terminals.
5. Insert a backup battery into the mounting housing. Connect the battery's terminals to the BAT+ / BAT- terminals on the communicator.

Note: When choosing a battery, it must be charged to 80% capacity within 24 hours, and the remaining capacity is reached within the next 48 hours to meet the requirements of the EN54 standard.

3.2 Connecting sensors

There are 10 terminals **IO1–IO10** (inputs) on the communicator board for connecting sensor circuits. The number of inputs can be expanded to 32 using input expanders (**IO-8**, **IO-MO**, **IO-LORA**, **IO8-LORA**). Any terminal can be set as an input and assigned zone attributes: circuit type (NO, NC, EOL, EOL_T, ATZ, ATZ_T); sensitivity to temporary circuit events; see chapter 6.6 ““Zones” window”.

Schematics for connecting sensors.




RT	R1	R2
2.2k	2.2k	4.7k
1k	1k	2.2k
5.6k	5.6k	3.3k
5.6k	3.3k	5.6k
3.3k	6.8k	3.3k
2.2k	4.7k	8.2k
10k	10k	5.6k




Communicator *FIRECOM* for fire alarm control panels


Normally open with End of line resistor (EOL)




Normally closed with End of line resistor (EOL)




Normally closed with End of line resistor, with tamper and wire fault recognition (EOL_T)



Normally closed without EOL (ATZ)




Normally closed with EOL, with tamper and wire fault recognition (ATZ_T)



3.3 Connecting smoke detectors


Schematic for connecting two-wire smoke detectors.

Schematic for connecting two-wire smoke detectors to "FLOOP" output. When this circuit diagram is used, the "Input" type "FC Fire sensor (FLOOP input)" must be specified in the "Zones" window. The alarm current of the fire detector must be more than 10mA. Up to 8 fire detectors can be connected to the "FLOOP" output.




Wiring diagrams for two-wire smoke detectors with relay module SM1. In order to connect the smoke detector circuit to the selected input, it is necessary to activate the input (IOx) and set the circuit type (NO, NC, EOL, EOL_T, ATZ, ATZ_T) (see 6.6 "Zones" window). To connect a smoke detector power circuit to the PGM output (IO10), the "Fire Sensor Reset" function must be assigned to the output (see chapter 6.7 "PGM" window).

* The relay is used to detect a broken cable and removal of a fire detector. If you do not use a relay (K1), then contact K1 must be short-circuited.




Or



Schematic for connecting four-wire smoke detectors.


In order to connect the smoke detector circuit to the selected input, it is necessary to activate the input (IOx) and set the circuit type (NO, NC, EOL, EOL_T, ATZ, ATZ_T) (see 6.6 "Zones" window "). To connect a four-wire smoke detector power circuit to the PGM output (IO10), the "Fire Sensor Reset" function must be assigned to the output (see chapter 6.7 "PGM" window").

* The relay is used to detect a broken cable and removal of a fire detector. If you do not use a relay (K1), then contact K1 must be short-circuited.




3.4 Schematic for connecting the communicator to a fire alarm control panel

If you want to monitor the status of the fire alarm panel, connect its corresponding outputs to the **FIRECOM** inputs. The outputs (PGM1, PGM2, PGM3) of the fire panel must be configured as panel status outputs (Alarm, Trouble, etc.).






3.5 Schematic for connecting the fire panel ESPA4.4.4




FIRECOM communicator settings with **TriKdisConfig** when connecting the **ESPA4.4.4** fire alarm control panel.

1. Choose the **ESPA4.4.4** fire alarm control panel.
2. Select connection type.
3. The **FIRECOM** communicator and the fire panel must have the same data transmission settings.




4. Enter phone numbers, e-mail of users who should get messages from the **FIRECOM**.






5. If you want the user to receive messages (or calls) about events, tick the **SMS** (or **Call**) box.




6. Configure the communication channel if messages should be sent to the CMS receiver. Event messages are transmitted using the SIA DC-09 protocol.




Test the system. Activate the fire alarm and check that *FIRECOM* messages are sent to the CMS (central monitoring station) and to *Protegeus2*.

3.6 Schematic for connecting the fire panel NSC Solution




FIRECOM communicator settings with *TrikdishConfig* when connecting the *NSC Solution* fire alarm control panel.


1. Choose the **NSC solution** fire alarm control panel.
2. The “**NSC slave address**” must not match the address of the connected fire panel modules.



3. Enter phone numbers, e-mail of users who should get messages from the *FIRECOM*.




4. Users will get SMS messages and phone calls about events that are ticked. You can add additional CID event codes in the **CID** column. You must enter **SMS text** messages next to new codes. If you want the user to receive messages (or calls) about events, tick the **SMS** (or **Call**) box.






5. Configure the communication channel if messages should be sent to the CMS receiver.




After setting up the **FIRECOM** communicator, turn on power supply the fire control panel. Wait for the fire control panel software to load. It is necessary to scan the modules connected to the RS485 bus on the fire control panel. On the fire control panel, press: **PROG.>INSTALLER>(Enter the installer code) 00000 OK>(Select) SETTINGS>ENTER>(Select) SCAN RS485>ENTER**. Wait for the scan to complete. Return to the main screen by pressing **"CANCEL"** twice.

Test the system. Activate the fire alarm and check that **FIRECOM** messages are sent to the CMS (central monitoring station) and to **Protegeus2**.

3.7 Schematic for connecting the fire panel INIM SMARTLINE




Slave mode must be set for the **INIM Smartline** panel when it is connected to the **FIRECOM** communicator via RS485 bus.




Note: You cannot connect the **FIRECOM** using the RS485 bus if repeaters are connected to the **INIM Smartline** panel. iO expansion modules are not supported when the **FIRECOM** is connected to the **INIM Smartline** panel via RS485 bus.

FIRECOM communicator settings with **TrikiDisConfig** when connecting the **INIM SMARTLINE** fire alarm control panel.


1. Choose the **Inim Smartline** fire alarm control panel.




2. Enter phone numbers, e-mail of users who should get messages from the *FIRECOM*.



3. Users will get SMS messages and phone calls about events that are ticked. You can add additional CID event codes in the **CID** column. You must enter **SMS text** messages next to new codes. If you want the user to receive messages (or calls) about events, tick the **SMS** (or **Call**) box.




4. Configure the communication channel if messages should be sent to the CMS receiver.






Test the system. Activate the fire alarm and check that **FIRECOM** messages are sent to the CMS (central monitoring station) and to **Protegas2**.

3.8 Schematic for connecting the fire panel C-TEC Cast ZFP




FIRECOM communicator settings with **TrikdisConfig** when connecting the **C-TEC Cast ZFP** fire alarm control panel.


1. Choose the **C-TEC Cast ZFP** fire alarm control panel.




2. Enter phone numbers, e-mail of users who should get messages from the **FIRECOM**.



3. Users will get SMS messages and phone calls about events that are ticked. You can add additional CID event codes in the **CID** column. You must enter **SMS text** messages next to new codes. If you want the user to receive messages (or calls) about events, tick the **SMS** (or **Call**) box.




4. Configure the communication channel if messages should be sent to the CMS receiver.




Install the **ZFPtools** program on your computer. Run the **ZFPtools** program. Turn on the power supply of the fire control panel. Wait until the fire panel software is loaded. Connect the fire panel to the computer using a USB2.0 A-B cable.

1. Open the "Node View" tab.






2. Download the fire panel settings to your computer.




3. Enter the code (default code – 4444).
4. Click „OK“.






Communicator *FIRECOM* for fire alarm control panels

- 5. Select „BMS Interface“.
- 6. Click on the free icon.




- 7. Click „Edit Devices“.





8. In the “**Device**” tab, enter the system name.




9. In the “**Properties**” tab, enter the system name.

10. Specify the “**ABUS RS485**” bus to which the *FIRECOM* communicator is connected.


11. Configure messages.

12. Write the settings to the fire panel.






- 13. Enter the code (default code – 4444).
- 14. Click „OK“.



The fire panel is programmed. Disconnect the cable from USB2.0 A-B of the fire panel.

Test the system. Activate the fire alarm and check that **FIRECOM** messages are sent to the CMS (central monitoring station) and to **Protegeus2**.

3.9 Schematic for connecting a temperature sensor




Temperature sensors should be connected according to the given schematic. Maxim®/Dallas® DS18S20, DS18B20 temperature sensors (up to 8) or AM2301 humidity and temperature sensor (up to 1) can be connected to the communicator **FIRECOM**.

If a wire longer than 0,5 meters is used to connect a temperature sensor, we recommend using **twisted pair cable (UTP4x2x0,5 or STP4x2x0,5)**.

The “+5V” terminal on the board is for supplying devices connected to the “1-Wire” data bus with 5 V DC voltage. The maximum output current is 0,2 A. The output is protected from overload. If the maximum allowed current is exceeded, the power will automatically be switched off. The communicator automatically recognizes and links connected devices.


3.10 Schematics for connecting a relay and an LED indicator



Using the relay terminals, it is possible to remotely control (turn on/off) various electrical devices. The communicator’s universal “I/O” terminal must be configured as an output (OUT) and must have the definition “Remote control” assigned.





3.11 Schematics of connecting the inputs of the fire panel to the communicator



According to the EN54 standard, the fire panel from the communicator must receive information about the failure of communication with the monitoring station, as well as about the successful received of messages to the monitoring station. It is necessary to connect the PGM outputs (for example: "Relay1" and "Relay2") of the communicator to the special inputs of the fire panel. The PGM output of "Relay1" must be set to "CMS fail". The PGM output of "Relay2" must be set to "ACK received". "Relay1" output is activated in case of violation of the communication channel with the CMS. "Relay2" output is activated for 5 sec. upon successful sending of a message to the CMS.


3.12 Schematics for connecting iO series expander modules

If the communicator *FIRECOM* needs to have more inputs IN or outputs OUT, connect a wired or wireless TRIKDIS *iO* series input and output expander. The *FIRECOM*'s configuration for expander modules is described in chapter 6.5 "Modules" window".





Schematics for connecting LORA modules.



3.13 Turning on the communicator

To turn on the communicator, first you need to turn on its power supply. The communicator's LED indicators must operate in the following way:

- The "STA" diode must blink in green – this indicates that the power supply voltage is sufficient;
- The "SIM" diode must be green solid and periodically blink in yellow no less than 3 times – the green color indicates that the SIM card is successfully registered on the mobile network, while the number of yellow flashes indicate the mobile signal strength. The "ETH" indicator lights up green when the communicator is connected to the LAN network.

Note: Sufficient 4G mobile network strength is 3 (three yellow flashes of the "SIM" indicator).
If you see fewer yellow flashes of the "SIM" diode, the strength of the mobile network is insufficient. We recommend choosing a different place for installing the communicator, changing the location of the antenna or using a more sensitive mobile antenna.
If the light indication is different, see chapter 1.4 "LED indication of operation" to find out the reason.
If all of the *FIRECOM* indicator lights are off, check the power supply and connections.




4 Quick configuration using *TrikdisConfig* software

1. Download the configuration software *TrikdisConfig* from www.trikdis.com (type “TrikdisConfig” in the search field) and install it.
2. Connect the *FIRECOM* to the computer using a USB Type-C cable.
3. Launch *TrikdisConfig*. The program will automatically recognize the connected device and will automatically open the *FIRECOM* configuration window.
4. Click the **Read [F4]** button to see the current parameters of the *FIRECOM*. If a window requesting the administrator or installer code opens, enter the 6-digit code.

Below we describe the settings you need to edit to make the controller send events to the *Protegeus2* app or to the Central Monitoring Station.


4.1 Settings for connecting to *Protegeus2* app

In the “System options” window, “SIM” settings group:



1. Enter the “SIM card PIN” code.
2. Change the “APN”. You will find the “APN” on the SIM operator’s website. “Internet” is universal and works in the networks of most operators.


In the “Users & Reporting” window, “Cloud application” settings group:



3. Tick the box “Enable cloud service”.
4. Change the *Protegeus2* “Cloud access Code” if you want users to be asked to enter it when they add the system in the *Protegeus2* app (default password – 123456).




In the “Reporting to CMS” window, “Settings” tab:



5. If a LAN cable is connected to the communicator, check the box „DHCP“ (automatic registration mode) so that the **FIRECOM** communicator will automatically read the network settings (subnet mask, gateway) and an IP address will be assigned to it.
6. The parameters for how the communicator will send messages to **Proteagus2** are set. Connection types are set in sequence. If the connection with the primary connection type fails, it switches to the next one and so on. If the fallback connection type succeeded in passing the message to **Proteagus2**, then the "Return to Primary" connection type will be attempted after a set time interval.


In the “Zones” window, “Zones settings” tab:



7. Tick the boxes if you want users to receive notifications to **Proteagus2** about changes in zone states.




In the “PGM” window, “Outputs” tab:



8. Tick the boxes if you want users to receive notifications to *Proteus2* about changes in PGM output states.

In the “System events” window, “Events” tab:



9. Tick the boxes if you want users to receive notifications to *Proteus2* about changes in the communicator’s internal event states.

After finishing configuration, click the **Write [F5]** button and disconnect the USB cable.

Note: See chapter 6 “Description of TrikdisConfig windows” to find more about other *FIRECOM* settings in *TrikdisConfig*.

4.2 Settings for connecting to Central Monitoring Station

In the “System Options” window, “System general” tab:




1. Enter the “Object ID” (account) number provided by the Central Monitoring Station (4 characters, 0-9, A-F. **Do not use FFFE, FFFF Object ID**).



Communicator *FIRECOM* for fire alarm control panels


2. Enter the "SIM card PIN" number.
3. Change the "APN". You will find the "APN" on the SIM operator's website. "Internet" is universal and works in the networks of most operators.

In the "Reporting to CMS" window, "Settings" tab:



4. If a LAN cable is connected to the communicator, check the box "DHCP" (automatic registration mode) so that the *FIRECOM* communicator will automatically read the network settings (subnet mask, gateway) and an IP address will be assigned to it.
5. The parameters for how the communicator will send messages to CMS are set. Connection types are set in sequence. If the connection with the primary connection type fails, it switches to the next one and so on. If the fallback connection type succeeded in passing the message to CMS, then the "Return to Primary" connection type will be attempted after a set time interval.

In the "Reporting to CMS" window, "Reporting" tab:



6. **Communication type** – choose a communication type (TCP or UDP).
7. **Domain or IP** – enter the receiver's domain or IP address.



Communicator *FIRECOM* for fire alarm control panels

8. **Port** – enter the receiver’s network port number.
9. **Protocol** – choose which transmission protocol should be used for sending messages: **TRK** (to TRIKDIS receivers), **DC-09_2007** or **DC-09_2012** (to universal receivers), **TL150** (to SUR-GARD receivers).
10. **Encryption Key** – enter the receiver’s encryption key.

Note: If you chose **DC-09** as the transmission protocol, additionally enter the object, line and receiver numbers in the “**Settings**” setting group of the “**Reporting to CMS**” window.

11. (Recommended) Configure the “**Backup channel**” settings.
12. Configure „**Parallel channel**” if messages will be sent to the second receiver of the CMS.

After finishing configuration, click the **Write [F5]** button and disconnect the USB cable.

Note: See chapter 6 “**Description of TrikdisConfig windows**” to find more about other *FIRECOM* settings in *TrikdisConfig*.

5 Remote control

5.1 Adding the communicator to *Protegeus2* app

Using *Protegeus2*, users can see the system’s state and receive notifications about system events.

1. Download and launch the *Protegeus2* app or use the browser version web.protegeus.app:



2. Create a new account or log in with your user name and password.

IMPORTANT: When adding the system to *Protegeus2* the *FIRECOM* communicator must:

1. Have an inserted and activated SIM card with the PIN code entered or disabled;
2. Have *Protegeus2* service enabled. See 6.4 “**Users & Reporting**” window;
3. Have the power switched on (“**STA**” LED must be blink green);
4. Be connected to a network (the “**SIM**” LED must be green solid and blink yellow; or/and “**ETH**” LED is green when connected to LAN network).



3. Click **"Add new system"** and enter the *FIRECOM*'s **"Unique ID"** number. It can be found on the device and packaging sticker. After entering the **"Unique ID"**, click the **"Next"** button.



5.2 Configuration and control via SMS messages

1. Change the administrator password

To ensure safety, change the default administrator SMS password. Send an SMS message of the following format:

PSW 123456 xxxxxx

- 123456** Default administrator password
- xxxxxx** New 6-symbol administrator password

2. Allow other users to control

Only phone numbers on the user list can control the system using SMS messages or phone calls. From an administrator phone, send SMS messages with other people's phone numbers and names to allow them to control the system:

SETN xxxxxx PHONEx=+PHONENR#NAME#EMAIL

- xxxxxx** 6-symbol administrator password
- x** User's number on the list. (If you write 1 as the user number, you will transfer your administrator's rights to the other user.)
- PHONENR** User's phone number
- NAME** User's name
- EMAIL** User's e-mail

SMS command list

Command	Data	Description
<i>INFO</i>		Request information about the communicator. Object name, partition state, IMEI number, GSM signal strength, firmware version and serial number will be included in the reply. E. g.: INFO 123456
<i>RESET</i>		Reset the device. E.g.: RESET 123456
<i>OUTPUTx</i>	<i>ON</i>	Turn on an output, "x" is the output number. E.g.: OUTPUT1 123456 ON
	<i>OFF</i>	Turn off an output, "x" is the output number. E.g.: OUTPUT1 123456 OFF



Communicator **FIRECOM** for fire alarm control panels

Command	Data	Description
	<i>PULSE=ttt</i>	Turn on an output for a few seconds - “x” is the OUT output number, and “ttt” is a three-digit number that specifies pulse time in seconds. E.g.: OUTPUT1 123456 PULSE=002
<i>PSW</i>	<i>New password</i>	Change password. E.g.: PSW 123456 654123
<i>TIME</i>	<i>YYYY/MM/DD,12:00:00</i>	Set date and time. E.g.: TIME 123456 2023/05/09,12:23:00
<i>TXTA</i>	<i>Object name</i>	Specify an object name. E.g.: TXTA 123456 House
<i>RDR</i>	<i>PhoneNR#SMStext</i>	Forward SMS messages to the specified number. The phone number must start with a “+” sign and the international country code. E.g.: RDR 123456 +37061234567#forwarded text
<i>ASKI</i>		Request SMS message about statuses of inputs IN. E.g.: ASKI 123456
<i>ASKO</i>		Request SMS message about statuses of outputs OUT. E.g.: ASKO 123456
<i>ASKT</i>		Send SMS message with values of all temperature sensors. E.g.: ASKT 123456
<i>FRS</i>		Resets the fire sensor’s output, if the output OUT is assigned the function “Fire sensor reset”. E.g.: FRS 123456
<i>SETN</i>	<i>PhoneX=PhoneNR#Name#email</i>	Add a phone number, username, e-mail and assign it to user “x”. “x” is the phone number’s line on the list. The phone number must start with a “+” symbol and international country code. The phone number and username must be separated by a “#” symbol. E.g.: SETN 123456 PHONE5=+37061234567#JOHN#jonas@trikdis.lt
	<i>PhoneX=DEL</i>	Delete user’s phone number and name from the system. E.g.: SETN 123456 PHONE5=DEL
<i>UUSD</i>	<i>*Usd code#</i>	Send a UUSD code to the operator. E.g.: UUSD 123456 *245#
<i>CONNECT</i>	<i>Protequs=ON</i>	Connect to Protequs cloud service. E.g.: CONNECT 123456 PROTEGUS=ON
	<i>Protequs=OFF</i>	Disconnect from Protequs cloud service. E.g.: CONNECT 123456 PROTEGUS=OFF
	<i>Code=123456</i>	Protequs cloud service code. E.g.: CONNECT 123456 CODE=123456
	<i>IP=0.0.0.0:8000</i>	Specify the main server’s connection channel’s TCP IP and Port. E.g.: CONNECT 123456 IP=0.0.0.0:8000
	<i>IP=0</i>	For turning off the main channel. E.g.: CONNECT 123456 IP=0
	<i>ENC=123456</i>	TRK encryption key. E.g.: CONNECT 123456 ENC=123456
	<i>APN=Internet</i>	APN name. E.g.: CONNECT 123456 APN=INTERNET
	<i>USER=user</i>	APN user. E.g.: CONNECT 123456 USER=User
	<i>PSW=password</i>	APN password. E.g.: CONNECT 123456 PSW=Password

5.3 Control PGM outputs using phone calls

Perform these actions if you want to control a PGM output remotely:

- The user must be allowed to control outputs OUT and the output OUT must have type “Remote control” assigned (using **TrikdisConfig**).
- Call the number of the **FIRECOM**’s SIM card. The **FIRECOM** will answer the call and you can dial commands using the phone’s keypad (see the table).



Mobile phone keyboard command list

Keyboard buttons	Function	Description
[output no]*[state no]#	Control selected output OUT	Controls the specified PGM output. State: [0] – output turned off; [1] – output turned on; [2] – turned off for pulse time; [3] – turned on for pulse time; (pulse time is specified in the TrikdisConfig software, “PGM” table) [*] – this symbol shows the end of the command. E.g. (turn on output 1): 1*1# E.g. (turn off output 1): 1*0# E.g. (turn on output 2 for “Pulse time” specified in the TrikdisConfig “PGM” table): 2*3#
#	Retry entering the command	If you made a mistake while entering the command, press “#” on the phone’s keyboard and enter the command again.

6 Description of **TrikdisConfig** windows

6.1 Description of **TrikdisConfig** status bar

Once the **FIRECOM** is connected, **TrikdisConfig** will display information about the connected device in its status bar.



Name	Description
IMEI/Unique ID	Device’s IMEI number
Status	Operational state
Device	Device type (must show FC_xxxx)
SN	Device’s serial number
BL	Bootloader version
FW	Device’s firmware version
HW	Device’s hardware version
State	Type of connection with the program (USB or remote)
Role	Access level (shown after access code is approved)

When the **Read [F4]** button is clicked, the program will read and show settings currently saved on the **FIRECOM**. With **TrikdisConfig**, set the required parameters using the following program window descriptions.



6.2 “System Options” window

“System general” tab

“General” settings group

- **Object ID** – if events are going to be sent to the CMS, enter the Object ID (4-symbol hexadecimal number, 0-9, A-F. **Do not use FFFE, FFFF Object ID**) given by the CMS.
- **Object name** – the name given to the object that will be used in SMS messages sent to the user.
- **Test period** - when the box is ticked, “Test” messages will be sent every set period.
- **Start test at** - tick the box and specify a time when test reports should be sent.
- **Clear Events after reset** – all unsend event messages will be deleted upon reset.
- **Text language** – set the preferred language and the specific symbols of that language will be used in SMS messages.
- You can **Suspend event reporting when ...** a number of **same events per ... s** happen.
- **Restore event reporting after ...** – set the time after which suspending of event reporting will be cancelled. The time can be anywhere from 0 to 999 minutes.
- **Call** – when an event occurs, the *FIRECOM* will call user(-s) as many times as is set. If the call is declined or answered, the *FIRECOM* will stop calling. Duration of a call is 20 seconds.
- **EOL Type** - specify the nominals of the resistors connected to the sensors (EOL – End Of Line. RT + R1 + R2. Resistor RT - tamper; resistor R1 - sensor No 1; resistor R2 - sensor No 2).
- **Communication path test** - specify the time interval after which the communicator will check the Backup communication channels by sending messages to the CMS. After sending the messages on the Backup communication channels, the communicator will return to the Primary communication channel.

“SIM” settings group

- Enter the “**SIM card PIN**” code.
- **APN** – network service provider’s mobile internet access point name. You must enter the **APN** if event messages will have to be sent to *Protegeus2* app or to the CMS via GPRS.
- If required by the GPRS network service provider, enter the **APN** user name and password in the fields **Login** and **Password**.
- **Locked ICCID** - enter the ICCID number of the SIM card if you want the communicator to work only with this SIM card.




“Time settings” settings group

You can set the time by clicking the “Set PC time” button. If “Disabled” is chosen in the “Time synchronization” field, the computer’s time will be set for the communicator. If a modem or a server is chosen in the “Time synchronization” field, the communicator will synchronize its time according to that modem or server.


- **Time zone (hours)** – specify your country’s time zone. For example, if the communicator will be installed in Lithuania, enter **+3**.
- **Time set** – specify a server to synchronize the *FIRECOM*’s internal clock with. Synchronization occurs after the communicator is powered on.
- **Daylight saving time** – if you check the box, the communicator’s internal clock will be automatically switched to summer or winter time.
- **Power failure delay** - in the event of a power failure in the main power supply, a power failure notification will be sent after the specified time delay. When the supply voltage is restored, a notification of the supply voltage recovery will be sent after the specified time delay.

“Groups” tab



Zones can be assigned to groups. The name of each group can be changed. Group names will be visible in *Protebus2*.

“Access” tab



Settings group “Access codes”

- **Administrator Code** – gives full access to configuration functions (default code – 123456).
- **SMS password** – password for remote control and programming via SMS messages (default code – 123456).
- **Installer Code** – gives limited access to changing the communicator’s configuration (default code – 654321).




Note: If the default *administrator code* is set (123456), after pressing **Read [F4]** the program will immediately show the current operational parameters of the device without asking for the code.

Settings group “Installer permissions”

The administrator can set which parameters can be changed by the installer.

6.3 “Reporting to CMS” window

“Reporting” tab



The communicator sends messages to the Central Monitoring Station using internet (IP).

You can assign a backup channel to the primary channel. It will be used when connection via the primary channel is lost.

Messages sent to the Central Monitoring Station are encoded and password protected. To receive messages and forward them to monitoring software, a TRIKDIS receiver is required:

- For IP messages – receiving program IPcom Windows/Linux, hardware IP/SMS receiver RL14 or multi-channel receiver RM14.

Settings group “Primary channel” (“Parallel channel”)

- **Communication type** – choose a method for connecting to the Central Monitoring Station’s receiver.
- **Domain or IP** – enter the receiver’s domain or IP address.
- **Port** – enter the receiver’s network port number.
- **Protocol** – select in which coding the events should be sent: **TRK** (to TRIKDIS receivers), **DC-09_2007** or **DC-09_2012** (to universal receivers. By selecting the SIA DC protocol, you can select the SIA-DCS messaging format.), **TL150** (to SUR-GUARD receivers).
- **Encryption Key** – 6-digit message encryption key. The communicator’s encryption key must match the receiver’s encryption key.


If parameters are set for the parallel channel, reports will be sent using both channels simultaneously. Both channels cannot be configured for the same receiver.

Settings group “Backup channel” (“Parallel backup channel”)

Enable backup channel mode to allow messages to be sent using the backup channel if the connectivity is disrupted. Configure the backup channel using the same settings as described above.



“Settings” tab



Settings group “Settings”

- **Return to Primary after** – time period after which the *FIRECOM* will attempt to regain connection with the “Primary channel”.
- **IP PING period** – sending period of internal PING signals for checking connectivity. These messages are sent only via IP channel. The receiver does not forward these signals to the monitoring software and thus does not overload the software. The monitoring software is only notified when the receiver does not receive a PING message from the device for a preset period of time.

By default, the receiver will send a “*Connection lost*” message to the monitoring software after a time period that is three times longer than the communicator’s PING sending period. E.g. if the IP PING period is 3 minutes, the receiver will send a lost connection message if it does not receive a PING for 9 minutes.

PING messages also keep an active connection session between the device and the receiver. An active session is required to configure and control the communicator remotely. We recommend setting the PING period to be no longer than 5 minutes.

- **Backup reporting after** – specify the number of unsuccessful attempts to send a message using the “**Primary channel**”. If the message fails to send after the specified number of attempts, the device will transmit using the “**Backup channel**”.
- **DNS1, DNS2** – (Domain Name System) server that specifies the domain IP address. It is used when a domain is specified in the connectivity channel’s “**Domain or IP**” field (instead of an IP address). Default setting - Google DNS server addresses.

The following settings are only shown when **DC-09_2007** or **DC-09_2012** protocol is chosen in the connectivity channel’s **Protocol** field.

- **Object ID in SIA DC-09** – enter the object number. If you chose the DC-09 protocol, the object number entered in this field will be used. You can enter the 3-16 symbol hexadecimal number given by the central monitoring station.
- **SIA DC-09 receiver No.** – enter the receiver’s number.
- **SIA DC-09 line No.** – enter the line number in the receiver.
- **Local time in SIA** - check the box so that the messages sent to the CMS indicate the time set in the module.

Settings group “Reporting mode”

For setting parameters on how the communicator will communicate with the CMS channels and with *Protegas2*. The connection types are specified in order. If the communicator fails to connect using the “**Main type**” connection , it switches to the “**Backup type**”, and so on. If the backup connection type was successful in transmitting the message to the CMS, then the “**Return to main**” connection type will be attempted after the specified time interval.



Communicator **FIRECOM** for fire alarm control panels

- **Main type** – select a connection type (SIM, Ethernet (LAN)) with the CMS receiver and **Proteagus2**.
- **Backup type** – select a connection type (SIM, Ethernet (LAN)) with the CMS receiver and **Proteagus2**.
- **Backup type 2** – select a connection type (SIM, Ethernet (LAN)) with the CMS receiver and **Proteagus2**.
- **Return to main (both channel)** – time period after which the **FIRECOM** will attempt to regain connection using the *primary* channel, if it was running a backup channel, min.

Settings group “LAN network parameters”

- **DHCP mode** – mode for registering on the LAN network (manual or automatic). Tick the box and the **FIRECOM** communicator will automatically read the network settings (subnet mask, gateway) and will automatically be assigned an IP address (automatic registration mode).
- **Static IP** – static IP address for manual registration mode.
- **Subnet mask** – subnet mask for manual registration mode.
- **Default gateway** – gateway for manual registration mode.
- **LAN Trouble indication** – check the box so that the LED on the communicator lights up when the LAN communication link fails.

Settings group “SIM parameters”

- **Disable indication of the absence of a SIM card** – when the box is ticked, the **FIRECOM** communicator will not display an indication that there is no SIM card inserted.
- **Use dial and SMS when working over internet module** – ticking this box will enable controlling the communicator using phone calls and SMS messages. If the box is not ticked and there is a LAN network available, then SMS and phone calls are not used. If the box is not ticked and there is no LAN network, the **FIRECOM** can still be controlled using phone calls and SMS messages. The **FIRECOM** will send SMS messages to the user.
- **Disable the use of SIM card mobile data** – ticking the box will disable the usage of the SIM card’s mobile data. Data will only be sent using LAN. If a LAN network is temporarily unavailable, the **FIRECOM** will store data in memory. When the LAN network is restored, the **FIRECOM** will send data using LAN.

6.4 “Users & Reporting” window

“Users” tab

ID	Name	Tel number	Email	PGM	ACK	FWD
1A	Jonas	+370698547	jonas@trikdis.it	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
2A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
3A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
4A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
5A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
8A				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10				<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Settings group “Users & Reporting to User”


- **ID** – user’s number on the list.
- **Name** – user’s name. These names will be used in event SMS messages and application.
- **Tel number** – the user’s phone number that will receive SMS messages. The numbers must start with the international country code. The first 8 telephone numbers will receive reports using messages and phone calls.
- **E-mail** - enter the user’s email, so that the user would be invited to **Proteagus2** to control the system.
- **PGM** – if the box is ticked, the user can remotely control outputs (calls, SMS).



Communicator *FIRECOM* for fire alarm control panels

- **ACK** – if the box is ticked, the *FIRECOM* will send SMS messages with “**SMS answer text**” to the user after every received SMS command.
- **FWD** – if the box is ticked, SMS messages received from non-system users will be forwarded to the user (e.g. SIM card account balance, random promotional messages, etc.).


“Protegun” tab



Settings group “Cloud application”

- **Enable cloud service** – enable *Protegun 2* service to allow the *FIRECOM* to exchange data with the *Protegun2* app and remotely configure the device using *TrikiDisConfig*.
- **Parallel reporting** – enable parallel message sending via the “**Primary channel**” and to *Protegun2*.
- **Cloud access code** – 6-digit code for logging in to *Protegun2* (default code - 123456).

“SMS answer texts” tab




Settings group “SMS answer texts”

The text for answers to commands sent using SMS messages can be customized in the column “**SMS text**”. Also here are the texts of SMS messages that are used when activating inputs or outputs.




6.5 “Modules” window

“RS485 modules” tab



Settings group “RS485 modules”

- **ID** – module’s number on the list.
- **Module** – choose the module being used (modules **iO-8**, **iO-MO**, **iO-LORA**, **iO8-LORA**, **PB-LORA**, **REL-LORA**) from the module list.
- **Serial No.** – mandatory 6-digit number that can be found on the module’s casing and its packaging.
- **Name** – you can give the module a name.
- **Firmware version** – the firmware version will be shown when the **FIRECOM** finds the connected module.



Settings group “RS485 2 modules”

Fire panels (**ESPA4.4.4**, **NSC solution**, **INIM smartline**, **C-TEC Cast ZFP**) can be connected to the RS485 2 bus of the **FIRECOM** communicator. The connection diagram of the fire panel and settings is shown in paragraphs 3.5-3.8.




6.6 “Zones” window

“Zones settings” tab



- **Zone No** – zone’s number on the list.
- **Name** - the zone can be given a name that will be used in SMS messages and application.
- **Input** – choose which **FIRECOM** or expansion module input IN to assign to a zone.
- **Group** - assigning a zone to a group.
- **Type** – choose the type of circuit connected to the zone input IN from a list: NC – normally closed; NO – normally open; EOL – with an end of line resistor; EOL_T – with an end of line resistor and tamper monitoring; ATZ – two zone normally closed circuit with end of line resistors, without tamper monitoring function (to use this type, choose the second ATZ zone in the input list); ATZ_T – two zone normally closed circuit with end of line resistors, with tamper monitoring function (to use this type, choose the second ATZ zone in the input list).
- **CMS** – if the box is ticked, messages about zone events will be sent to the CMS (central monitoring station).
- **Prot.** – if the box is ticked, notifications about zone events will be sent to **Protegeus2** app.
- **Delay** – IN input zone reaction time in milliseconds.

“SMS & Call reporting” tab




This window will only be displayed if at least one user phone number has been added to the „Users & Reporting“ window.

- **Zn** – zone number with an event identification word. Can be “Event” or “Restore”.
- **User SMS/Call** – choose how to inform users about every zone event – via SMS message and/or call.



“Zone’s codes” tab




When the zone is triggered, the communicator will send an event message. The input is assigned a Contact ID (SIA) code, which will be sent to CMS and *Protegeus2*.

- **Enable** – checked event fields where messages will be sent to CMS and *Protegeus2*.
- **E/R** – choose what type of event will be sent when input is triggered – “Event” (E) or “Restore” (R).
- **CID** – enter the event code or leave the default value.
- **SIA** - event SIA codes.
- **Group** – enter the group number that will be sent when an event occurs.
- **Zone** - enter the zone number that will be sent when an event occurs.

6.7 “PGM” window


“Outputs” tab



- **PGM No** – PGM output’s number on the list.
- **Name** - enter the name of the PGM output.
- **PGM output** – assign outputs OUT of the *FIRECOM* or of an external device to a PGM.
- **Output definition** – select operational mode of an output OUT.
- **Pulse time, s** – assign a desired OUT turn on duration from 0 to 9999 seconds.
- **CMS** – if the box is ticked, messages about chosen events will be sent to CMS.
- **Prot.** – if the box is ticked, output event notifications will be sent to *Protegeus2* app.




“Set Action” tab



- **ID** – output’s number on the list.
- **Enable** – enables the PGM operation algorithm.
- **PGM No.** – select the desired PGM output OUT that will be controlled after the event described in columns “**Factor**”, “**Factor No.**”, “**Start when**”, “**Set value**” occurs.
- **Action:**
 - **PGM OFF** – state of output OUT – “Off”.
 - **PGM ON** – state of output OUT – “On”.
 - **Pulse OFF** – initial state of output OUT – “On”. After the command the OUT state will become “Off” for the duration of the “**Pulse time**”, and later it will automatically return to the initial “On” state.
 - **Pulse ON** – initial state of output OUT – “Off”. After the command the OUT state will become “On” for the duration of the “**Pulse time**”, and later it will automatically return to the initial “Off” state.
- **Pulse time, s** – you can set the pulse time anywhere from 0 to 9999 seconds.
- **Factor/Factor No.** – choose what event (*Zone, SMS received, Zone tamper*) will turn on the output OUT.
- **Start when** – you can set an additional condition when to turn on the output OUT depending on the “**Factor**” event.
- **Set value** – depending on the condition chosen in the “**Factor**” column a value (text of received SMS message) can be specified. If this value is identified, the action (chosen in the “**Action**” column) will be performed. The text of the SMS message can be separated by using % symbols. % symbols are used for separating the keyword that will change the state of a PGM output from the entire received SMS message.
 - %....% - part of the received SMS message text must match with the text entered between % symbols (e.g. %**hoUSe**%). The text in an SMS message must include the text “**hoUSe**”. Example of an SMS message: **VacationhoUSe25864**).
 -% - the beginning of the received SMS message must match the text entered until the % symbol (e.g. **hoUSe**%. The SMS message must start with the text “**hoUSe**”. Example of an SMS message: **hoUSeddss**).
 - %.... – the ending of the received SMS message must match with the text entered after the % symbol. (e.g. %**hoUSe**). The SMS message must end with the text “**hoUSe**”. Example of an SMS message: **1144hoUSe**).

The SMS message text is case-sensitive.

“Scheduler” tab




- **ID** – schedule’s number on the list.
- **Enable** – enable the schedule.
- **Start time** – set the time when OUT will be turned on (schedule start time).



Communicator FIRECOM for fire alarm control panels

- **Stop time** – set the time when OUT will be turned off (schedule end time).
 - **Mon – Sun** – you can mark the days of the week when OUT will have to be turned on/off.


“SMS & Call reporting” tab



This tab will only be displayed if there is at least one user phone number in the "Users & Reporting" window. These settings can only be made for the first 8 users.

- **PGM** – the number of output OUT and turn on/off event type (“Event” – output OUT turn on event and “Restore” – OUT turn off event).
- **User SMS/Call** – choose which users to inform via SMS message and/or call when an output OUT is turned on/off.

6.8 “Sensors” windows



- **ID** – temperature sensor’s number on the list.
- **Module type** – choose a temperature sensor to assign to the ID.
- **Serial No.** - serial number of the temperature sensor read by the communicator.
- **Sensor name** – give the temperature sensor a name.
- **Max** – when the temperature is higher than this setting, an event report will be generated. For an event message to be generated, the “**High**” box must be ticked.
- **Min** – when the temperature is lower than this setting, an event report will be generated. For an event message to be generated, the “**Low**” box must be ticked.
- **Sensor type** – choose the type of the connected temperature sensor (Dallas 1Wire – up to 8 temperature sensors of this type can be connected. If Dallas sensors are chosen, they will be linked automatically; Humidity & Temperature – one AM2301 temperature and humidity sensor can be connected. If the Humidity & Temperature sensor will be used, it must be manually assigned in the “**Module type**” column).



6.9 "System events" window

"Events" tab

ID	Event name	Enable	CMS	Prot.	CID Code	SMS event text	SMS restore text
1	Low Battery	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	302	Battery low	Battery restore
2	Periodic test	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	602	Periodic test	
3	Battery missing	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	311	Battery missing	Battery restore
4	RS485 fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	333	RS485 device fault	RS485 device restore
5	High temperature	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	158	High value	Value restored
6	Low temperature	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	159	Low value	Value restored
7	Temp. sensor lost	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	380	Sensor fault	Sensor restore

- **ID** – event’s number on the list.
- **Event name** – event name.
- **Enable** – enable event recognition.
- **CMS** – messages about chosen events will be sent to CMS.
- **Prot.** – notifications about chosen events will be sent to **Protegeus 2** app.
- **CID Code** – event’s Contact ID code.
- **SMS event text** – text of the event’s SMS message.
- **SMS restore text** - text of the event’s restore SMS message.

"SMS & Call reporting" tab


ID	Event SMS text	User 1	
		SMS	Call
	Check/uncheck all rows:	<input type="checkbox"/>	<input type="checkbox"/>
1 Event	Battery low	<input type="checkbox"/>	<input type="checkbox"/>
1 Restore	Battery restore	<input type="checkbox"/>	<input type="checkbox"/>
2 Event	Periodic test	<input type="checkbox"/>	<input type="checkbox"/>
3 Event	Battery missing	<input type="checkbox"/>	<input type="checkbox"/>
3 Restore	Battery restore	<input type="checkbox"/>	<input type="checkbox"/>

This tab will only be displayed if there is at least one user phone number in the "Users & Reporting" window

- **ID** – number and identification word (*Event, Restore*) of the event.
- **Event SMS text** – text that will be used in event SMS messages.
- **User SMS/Call** – choose the ways users will be informed about each event – SMS message and/or phone call.




6.10 “Events Log” window



- **Read Log** button – for reading the event log from the device’s memory.
- **Clear Log** button – for clearing the event log entries from the device’s memory.
- In the table, you can find the “**Event No.**”, “**Time**”, “**CID**” code, “**Event definition**”. The events log can show up to 1000 events stored in the **FIRECOM**’s memory.

6.11 Restore default settings

To restore the communicator’s default settings, click the **TrikiDisConfig** button “**Restore**”.




7 Setting parameters remotely

IMPORTANT: Remote configuration will only work when the **FIRECOM**:

1. Has an inserted and activated SIM card with the PIN code entered or disabled.
2. Has **Protegeus** service enabled. See **6.4 “Users & Reporting” window**.
3. Has the power switched on (“**STA**” LED must be blink green);
4. Is connected to a network (the “**SIM**” LED must be green solid and blink yellow; or/and “**ETH**” LED is green when connected to LAN network).

If “**SIM**” is yellow solid or “**DAT**” is yellow solid, the device cannot connect to GSM and/or **Protegeus2**.

1. On your computer, launch the configuration software **TrikiDisConfig**.
2. In the “**Remote access**” window, enter the communicator’s “**Unique ID**” number. You can find this number on the back of the device and on the device’s packaging.



3. (Optional) Enter a desired name for the communicator in the “**System Name**” field.
4. Click “**Configure**”.
5. In the window that opens, click **Read [F4]**. If prompted, enter the administrator or installer code.
6. When you are finished setting the desired parameters, click **Write [F5]**. If you are done working with *TrikiDisConfig*, click “**Disconnect**”.

8 Communicator testing

When configuration and installation are complete, perform a system check:


1. To test an input of the communicator, enable it. Check if the events were received by the Central Monitoring Station (CMS) and/or *Protegeus2* application.
2. To test the communicator’s outputs, turn them on remotely and check their operation. Ensure that the events were received by the Central Monitoring Station (CMS) and/or *Protegeus2* application.
3. Perform a fire alarm test to see if the CMS receives events correctly.

9 Updating firmware

Note: After connecting the communicator to *TrikiDisConfig*, the program will automatically offer to update the firmware if any updates are available. Internet connection is needed for this feature. Antivirus software, firewall or strict internet access settings can block the automatic update feature. In this case, you will have to reconfigure your antivirus software.

The communicator’s firmware can also be updated or changed manually. All prior settings of the communicator remain after an update. If the firmware is installed manually, it can be changed to a newer or an older version. Perform these steps:

1. Launch *TrikiDisConfig*.
2. Connect the communicator to the computer using a USB Type-C cable or connect to the communicator remotely.
3. If a newer version of firmware is available, the program will automatically offer to install it.
4. Open the *TrikiDisConfig* window “**Firmware**”.



5. Click the button “**Open firmware**” and choose the required firmware file.
6. Click the **Update [F12]** button.
7. Wait for the update to finish.