

RF-LORA transceiver and *iO-8-LORA*, *iO-LORA* wireless expanders

Quick installation guide

Wireless expanders *iO-8-LORA*, *iO-LORA* with *RF-LORA* module increase the number of inputs and outputs of the "FLEXi" *SP3* control panel using two-way RF communication.




iO-8-LORA has 8 input/output terminals that can be configured as input or output.

iO-LORA has 1 input, 1 relay output, „1-Wire“ data bus for connecting temperature sensors (up to 4 pcs.) and a iButton key reader.



Visit the *iO-8-LORA*, *iO-LORA* page on trikdis.com for device specifications and an updated list of compatible *TRIKDIS* devices.

Follow the steps below to set up *iO-8-LORA*, *iO-LORA*:

1. Connect the *RF-LORA* transceiver to the "FLEXi" *SP3* control panel, and *iO-LORA*, *iO-8-LORA* to the power supply, as shown:



2. Input connection diagrams and resistor values are determined by the „FLEXi“ *SP3* control panel, to which the *iO-8-LORA*, *iO-LORA* modules are connected.
3. Schematics for connecting a relay and an LED indicator:



4. Connect a USB cable to the „**FLEXi**“ **SP3** control panel and open **TrikdisConfig** software. Press **Read [F4]**.
5. Go to the "**Modules**" window and click on an empty row in the "**RS485 Modules**" area. Select **iO-8-LORA Expander (iO-LORA Expander)** from the drop down list as shown:

System Options	Keypads	RS485 modules
Reporting to CMS	RS485 modules	
Users & Reporting	ID	Module
Modules	1	iO-LORA expander
Wireless	2	iO8-LORA expander
Zones	3	Not available
		Serial No.
		000009
		000005

6. Enter the serial number of the **iO-8-LORA (iO-LORA)** expander in the field on the right (enter numbers only). You will find serial number on the sticker on **iO-8-LORA (iO-LORA)**.
7. The „**Zones**“ and „**PGM**“ outputs menu windows will now display the inputs and outputs of the **iO-8-LORA (iO-LORA)** expanders that you can activate:

System Options	Zones settings	SMS & Call reporting
Reporting to CMS	Zone Name	Input
Users & Reporting	1	Zone 1
Modules	2	Zone 2
Wireless	3	Zone 3
Zones	4	Zone 4
PGM	5	Zone 5
	6	Zone 6
		Area
		Definition
		Type
		1
		Keyswitch
		ant Sta
		NO
		RS485 Expander ID1, IN1
		ant
		NO
		RS485 Expander ID2, IO1
		ant Sta
		NO
		RS485 Expander ID2, IO2
		ant Sta
		NO
		RS485 Expander ID2, IO3
		ant
		NO

8. Make the necessary settings and press **Write [F5]** and disconnect the USB cable.
9. Trigger the inputs and switch outputs to test the device.